

**BIC Models 911, 912,
912C, 914 and 914C**


Part number may change. When
ordering parts indicate model number,
part number and description.

Official Parts List B·C Models 911, 912, 912C, 914 and 914C

REF. NO.	911 PART NO.	912 PART NO.	912C PART NO.	914 PART NO.	914C PART NO.	DESCRIPTION
1	—	—	—	—	37-143-01	T/T "c" clip
2	37-302-01	37-302-01	37-267-01	37-267-01	37-267-01	T/T mat
3	10-366-02	10-366-02	38-385-01	38-385-01	38-385-01	Trim ring-sm (not shown)
4	37-130-01	37-130-01	38-180-01	38-180-01	38-180-01	Trim ring-lg (not shown)
5	—	—	10-366-02	10-366-02	10-366-02	T/T w/mat
6	—	—	37-130-01	37-130-01	37-130-01	Drive belt
7	—	—	20-060-01	20-060-01	20-060-01	Record support
8	10-319-01	10-319-01	10-319-01	10-319-01	10-319-01	Set screw
9	20-060-01	20-060-01	20-060-01	20-060-01	20-060-01	Trim screw
10	38-159-01	38-161-01	38-160-01	38-161-02	38-160-02	Control escutcheon insert
11	38-162-02	38-162-01	38-162-01	38-162-01	38-162-01	Trim-play key
12	10-393-02	10-393-01	10-393-01	10-393-01	10-393-01	Play key w/trim
13	10-370-01	10-370-01	10-370-01	10-382-01	10-382-01	Counterbalance wgt.
14	37-268-02	37-268-02	37-268-01	37-268-02	37-268-01	T/A slot cover
15	10-322-07	10-322-06	10-322-06	10-322-07	10-322-06	Top trim
16	37-251-01	37-251-01	37-251-01	37-251-01	37-251-01	Lens anti-skate
17	10-368-01	10-368-01	10-368-01	—	—	Pivot pin—fixed
18	10-369-01	10-369-01	10-369-01	—	—	Gimbal
19	38-155-01	38-155-01	38-155-01	—	—	Trim-gimbal (not shown)
20	10-367-01	10-367-01	10-367-01	—	—	Pivot pin—floating
21	37-309-01	37-309-01	37-309-01	—	—	Ping—T/A tube
22	10-327-01	10-327-01	10-327-01	—	—	Pivot (2)
23	20-484-01	20-484-01	20-484-01	—	—	Screw (2)
24	37-234-01	37-234-01	37-234-01	—	—	Pivot block
25	38-146-01	38-146-01	38-146-01	—	—	Trim—pivot blk (not shown)
26	36-037-01	36-037-01	36-037-01	—	—	Teamam tube
27	10-321-01	10-321-01	10-321-01	—	—	Head shell assy.
28	10-085-01	10-085-01	10-085-01	—	—	(nos. 26, 27, 29, 30)
29	20-268-01	20-268-01	20-268-01	—	—	Bkt. mfg. screw
30	10-372-02	10-372-02	10-372-02	—	—	Washer (not shown)
31	—	—	—	—	—	"c" clip (not shown)
32	39-220-01	39-220-01	39-220-01	—	—	Screw
33	22-027-01	22-027-01	22-027-01	—	—	Cart. mfg. Bkt. & nut assy.
34	23-256-01	23-256-01	23-256-01	—	—	Bearing
35	20-063-01	20-063-01	20-063-01	—	—	Cue rate knob
36	10-419-01	10-419-01	10-419-01	—	—	Cylinder—lift pin
37	21-005-01	21-005-01	21-005-01	—	—	P/U hgt. adj. screw
38	27-366-01	27-366-01	27-366-01	—	—	"c" clip
39	22-007-01	22-007-01	22-007-01	—	—	Spring—brake rod
40	37-250-01	37-250-01	37-250-01	—	—	Washer—brake rod
41	39-172-01	39-172-01	39-172-01	—	—	"c" clip—brake rod
42	20-263-01	20-263-01	20-263-01	—	—	Brake rod
43	36-025-02	36-025-02	36-025-02	—	—	Spring—brake bias
44	23-525-01	23-525-01	23-525-01	—	—	Lift pin & pivot assy.
45	40-257-01	40-257-01	40-257-01	—	—	Rocker plate
46	22-343-01	22-343-01	22-343-01	—	—	Washer—rocker plate
47	23-543-01	23-543-01	23-543-01	—	—	Spring—rocker plate
48	39-139-01	39-139-01	39-139-01	—	—	Screw—rocker plate
49	40-493-01	40-493-01	40-493-01	—	—	Return spring
50	10-062-02	10-062-02	10-062-02	—	—	Stroke window
51	38-563-01	38-563-01	38-563-01	—	—	Patnut (2)
52	22-003-01	22-003-01	22-003-01	—	—	Trim—stroke window
53	40-258-01	40-258-01	40-258-01	—	—	
54	39-369-01	39-369-01	39-369-01	—	—	
55	40-035-01	40-035-01	40-035-01	—	—	
56	37-294-01	37-294-01	37-294-01	—	—	
57	21-282-01	21-282-01	21-282-01	—	—	
58	38-171-01	38-171-01	38-171-01	—	—	
59	—	—	—	—	—	
60	—	—	—	—	—	
61	—	—	—	—	—	
62	—	—	—	—	—	
63	—	—	—	—	—	
64	—	—	—	—	—	
65	—	—	—	—	—	
66	—	—	—	—	—	
67	—	—	—	—	—	
68	—	—	—	—	—	
69	—	—	—	—	—	
70	—	—	—	—	—	
71	—	—	—	—	—	
72	—	—	—	—	—	
73	—	—	—	—	—	
74	—	—	—	—	—	
75	—	—	—	—	—	
76	—	—	—	—	—	
77	—	—	—	—	—	
78	—	—	—	—	—	
79	—	—	—	—	—	
80	—	—	—	—	—	
81	—	—	—	—	—	
82	—	—	—	—	—	
83	—	—	—	—	—	
84	—	—	—	—	—	
85	—	—	—	—	—	
86	—	—	—	—	—	
87	—	—	—	—	—	
88	—	—	—	—	—	
89	—	—	—	—	—	
90	—	—	—	—	—	
91	—	—	—	—	—	
92	—	—	—	—	—	
93	—	—	—	—	—	
94	—	—	—	—	—	
95	—	—	—	—	—	
96	—	—	—	—	—	
97	—	—	—	—	—	
98	—	—	—	—	—	
99	—	—	—	—	—	
100	—	—	—	—	—	
101	—	—	—	—	—	
102	—	—	—	—	—	
103	—	—	—	—	—	
104	—	—	—	—	—	
105	—	—	—	—	—	
106	—	—	—	—	—	
107	—	—	—	—	—	
108	—	—	—	—	—	
109	—	—	—	—	—	

Official Parts List B1C Models 911, 912, 912C, 914 and 914C (Continued)

REF.	911	912	912C	914	914C	DESCRIPTION	REF.	911	912	912C	914	914C	DESCRIPTION
110	---	41-015-01	41-015-01	41-015-01	41-015-01	Reject rod	167	21-280-01	21-280-01	21-280-01	21-280-01	21-280-01	Nut
111	---	40-286-01	40-286-01	40-286-01	40-286-01	Spring—reject rod	168	10-106-01	10-106-01	10-106-01	10-106-01	10-106-01	Ground lead
112	38-122-01	38-122-01	38-122-01	38-122-01	38-122-01	Cue link	169	37-375-02	37-375-02	37-375-02	37-375-02	37-375-02	Screw—VIA wheel
113	20-268-02	20-268-02	20-268-02	20-268-02	20-268-02	Screw—cue link	170	37-328-01	37-328-01	37-328-01	37-328-01	37-328-01	Ball—pitch control (sm.)
114	38-122-01	38-122-01	38-122-01	38-122-01	38-122-01	Spring—cue link	171	37-301-01	37-301-01	37-301-01	37-301-01	37-301-01	Idler pulley
115	37-205-01	37-205-01	37-205-01	37-205-01	37-205-01	Cue mounting Bkt.	172	23-180-01	23-180-01	23-180-01	23-180-01	23-180-01	"c" clip
116	37-204-01	37-204-01	37-204-01	37-204-01	37-204-01	Cue spool	173	37-328-02	37-328-02	37-328-02	37-328-02	37-328-02	Ball—pitch control (lg.)
117	20-013-02	20-013-02	20-013-02	20-013-02	20-013-02	Screw	174	37-297-01	37-297-01	37-297-01	37-297-01	37-297-01	Knob—viewing angle
118	20-187-01	20-187-01	20-187-01	20-187-01	20-187-01	Screw	175	38-073-01	38-073-01	38-073-01	38-073-01	38-073-01	Knob—viewing angle
119	20-064-01	20-064-01	20-064-01	20-064-01	20-064-01	Screw	176	23-180-01	23-180-01	23-180-01	23-180-01	23-180-01	Bowed washer
120	36-045-01	36-045-01	36-045-01	36-045-01	36-045-01	Cue lever	177	37-298-01	37-298-01	37-298-01	37-298-01	37-298-01	Knob—pitch control
121	---	40-031-01	40-031-01	40-031-01	40-031-01	Spring—program plate	178	38-168-01	38-168-01	38-168-01	38-168-01	38-168-01	Pivot bracket
122	---	40-032-01	40-032-01	40-032-01	40-032-01	Spring—secondary plate	179	27-032-01	27-032-01	27-032-01	27-032-01	27-032-01	Mirror
123	---	37-199-02	37-199-01	37-199-02	37-199-01	Secondary program plate	180	37-295-01	37-295-01	37-295-01	37-295-01	37-295-01	Mirror bracket
124	---	37-198-02	37-198-01	37-198-02	37-198-01	Program plate	181	37-189-01	37-189-01	37-189-01	37-189-01	37-189-01	VIA wheel
125	---	17-567-02	17-567-02	17-567-02	17-567-02	Sleeve	182	20-181-02	20-181-02	20-181-02	20-181-02	20-181-02	Screw
126	---	40-564-01	40-564-01	40-564-01	40-564-01	Spring—slip lever	183	37-314-01	37-314-01	37-314-01	37-314-01	37-314-01	Lift pulley
127	---	38-137-01	38-137-01	38-137-01	38-137-01	Stop lever	184	39-156-01	39-156-01	39-156-01	39-156-01	39-156-01	Stand off—motor
128	---	40-286-01	40-286-01	40-286-01	40-286-01	Spring size selector lever	185	10-423-01	10-423-01	10-423-01	10-423-01	10-423-01	Motor
129	---	10-309-01	10-309-01	10-309-01	10-309-01	Size selector lever	186	39-185-01	39-185-01	39-185-01	39-185-01	39-185-01	Spacer
130	---	40-283-01	40-283-01	40-283-01	40-283-01	Spring—compression	187	10-356-01	10-356-01	10-356-01	10-356-01	10-356-01	Set screw
131	---	23-292-01	23-292-01	23-292-01	23-292-01	"c" clip	188	10-408-01	10-408-01	10-408-01	10-408-01	10-408-01	60 Hz pulley
132	---	37-265-01	37-265-01	37-265-01	37-265-01	Drive plate bracket	189	20-422-01	20-422-01	20-422-01	20-422-01	20-422-01	50 Hz pulley
133	---	10-307-01	10-307-01	10-307-01	10-307-01	Drive plate	190	37-305-01	37-305-01	37-305-01	37-305-01	37-305-01	Set screw
134	---	38-541-01	38-541-01	38-541-01	38-541-01	Bias plate	191	10-361-01	10-361-01	10-361-01	10-361-01	10-361-01	Motor plate
135	---	22-560-01	22-560-01	22-560-01	22-560-01	Fibre washer	192	21-280-01	21-280-01	21-280-01	21-280-01	21-280-01	Nut
136	---	40-155-01	40-155-01	40-155-01	40-155-01	Spring—override	193	37-134-01	37-134-01	37-134-01	37-134-01	37-134-01	Speed cam
137	---	23-292-01	23-292-01	23-292-01	23-292-01	"c" clip	194	40-302-01	40-302-01	40-302-01	40-302-01	40-302-01	Spring
138	---	40-371-01	40-371-01	40-371-01	40-371-01	Spring—drive plate	195	23-292-01	23-292-01	23-292-01	23-292-01	23-292-01	"c" clip
139	10-386-01	10-386-01	10-386-01	10-386-01	10-386-01	Line cord	196	---	---	---	---	---	Counterbalance wgt.
140	20-181-01	20-181-01	20-181-01	20-181-01	20-181-01	Screw	197	---	---	---	---	---	Tube, CB wgt.
141	10-320-01	10-320-01	10-320-01	10-320-01	10-320-01	Photo socket	198	---	---	---	---	---	Fixed pivot
142	20-293-03	20-293-03	20-293-03	20-293-03	20-293-03	Screw	199	---	---	---	---	---	Gimbal
143	39-227-01	39-227-01	39-227-01	39-227-01	39-227-01	Nut—VIA foot (4)	200	---	---	---	---	---	Flaring pivot
144	10-420-01	10-420-01	10-420-01	10-420-01	10-420-01	VIA foot (4)	201	---	---	---	---	---	Screw
145	39-144-01	39-144-01	39-144-01	39-144-01	39-144-01	Transit screw (4)	202	---	---	---	---	---	Screw—allen
146	23-180-01	23-180-01	23-180-01	23-180-01	23-180-01	"c" clip (4)	203	---	---	---	---	---	Pivot & tube assy.
147	22-023-01	22-023-01	22-023-01	22-023-01	22-023-01	Washer (4)	204	---	---	---	---	---	Levelled pivot
148	37-182-01	37-182-01	37-182-01	37-182-01	37-182-01	Grommet (4)	205	37-213-01	37-213-01	37-213-01	37-213-01	37-213-01	Stylus pressure spring
149	37-188-01	37-188-01	37-188-01	37-188-01	37-188-01	Rate adjuster	206	---	---	---	---	---	Ring—stylus force
150	21-280-01	21-280-01	21-280-01	21-280-01	21-280-01	Nut	207	---	---	---	---	---	Locking collar
151	10-316-01	10-316-01	10-316-01	10-316-01	10-316-01	VIA spring assy.	208	---	---	---	---	---	Plug-in tone arm—includes nos. 206, 208, 210, 213
152	37-278-01	37-278-01	37-278-01	37-278-01	37-278-01	Mounting block	209	---	---	---	---	---	Tube w/harness
153	20-293-02	20-293-02	20-293-02	20-293-02	20-293-02	Screw	210	---	---	---	---	---	Bkt. mtg. screw
154	22-012-01	22-012-01	22-012-01	22-012-01	22-012-01	Master	211	---	---	---	---	---	P/U head
155	20-047-01	20-047-01	20-047-01	20-047-01	20-047-01	Screw—VIA wheel	212	---	---	---	---	---	Screw—reflector Bkt.
156	20-268-02	20-268-02	20-268-02	20-268-02	20-268-02	Screw—reflector Bkt.	213	---	---	---	---	---	Part. mtg. 6 Bkt.
157	20-187-01	20-187-01	20-187-01	20-187-01	20-187-01	Screw—terminal strip	214	---	---	---	---	---	Hex nut
158	27-030-01	27-030-01	27-030-01	27-030-01	27-030-01	Belt—VIA	215	---	---	---	---	---	Screw
159	12-057-04	12-057-04	12-057-04	12-057-04	12-057-04	Heyco—line cord	216	---	---	---	---	---	Manual spindle—rotating
160	12-057-01	12-057-01	12-057-01	12-057-01	12-057-01	Heyco—grid, lead	217	---	---	---	---	---	Manual spindle—fixed
161	38-201-01	38-201-01	38-201-01	38-201-01	38-201-01	Spacer—rate adj. pulley	218	---	---	---	---	---	Fixing screw—(2)
162	37-258-01	37-258-01	37-258-01	37-258-01	37-258-01	Timing pulley	219	---	---	---	---	---	Screwdriver
163	23-180-01	23-180-01	23-180-01	23-180-01	23-180-01	"c" clip	220	---	---	---	---	---	Automatic spindle
164	28-192-01	28-192-01	28-192-01	28-192-01	28-192-01	Insulator	221	---	---	---	---	---	45 rpm manual adaptor
165	21-280-01	21-280-01	21-280-01	21-280-01	21-280-01	Nut	222	---	---	---	---	---	Gauge—stylus overhang
166	10-162-10	10-162-10	10-162-10	10-162-10	10-162-10	Terminal strip assy.	223	---	---	---	---	---	Gauge—20° tracking angle
167	14-252-01	14-252-01	14-252-01	14-252-01	14-252-01	Capacitor—22 mfd.	224	---	---	---	---	---	Cartridge mtg. screws
168	14-374-01	14-374-01	14-374-01	14-374-01	14-374-01	Capacitor—pop filter	225	---	---	---	---	---	Audio cable
169	12-043-02	12-043-02	12-043-02	12-043-02	12-043-02	Choke	226	---	---	---	---	---	---



BIC Models 916MP | 916MPC

Part numbers may change. When ordering parts indicate model number, part number and description.